

# Hyosung MS-500 TCR Cleaning Instructions

## Cleaning Product Needed:

1. DataVac Duster
2. Waffletechnology Cleaning Card (*MiracleMagic*)
3. 6" Cleaning Swab (*MiracleMagic*)

---

## TCR Preparation for Cleaning

 *Wear eye protection when using Duster*

Step 1: Power off the TCR software

Step 2: Unlock and open the lower door

Step 3: Unlock and pull open the upper track

Step 4: Locate the red power switch and power down the TCR

## Cleaning Instructions

Step 1: Using the DataVac Duster, remove dust and debris from the following target areas:

- Cash Deposit Bin
- Reject Slot
- Transport Feed Path
- Bill Pathway
- Bill Validator
- Rear Transport Area (*including pathway*)
- Lower Feed Pathway (*support panel while unlatching*)

Step 2: Open the Bill Validator

Step 3: Using the 6in Cleaning Swab, clean all lenses and the silver magnetic read head

Step 4: Upon completion, dispose of cleaning swab

Step 5: Close all sections and power on the TCR

Step 6: In the Teller Application Software, select the "Deposit" function

Step 7: Place the Waffletechnology Cleaning Card in the Cash Deposit Bin

Step 8: After the card has cycled through, remove from the Reject Slot

Step 9: Without flipping the card, repeat steps 6 thru 8

Note: One cleaning card can be cycled through up to four times. Use another cleaning card if additional cleaning is needed

Step 10: Upon completion, dispose cleaning card and return TCR to service